

clockwise until tight.

2) Remove the Mounting Bracket, drill 4 holes for 3MM diameter, install the mounting bracket onto wooden ceiling with the 4Self Tapping Screws & Washers

Fanchange dirsction.(capprox.02sec)