
Thank you for purchasing this quality product. Be sure to check all packing material carefully for small part that may have come loose inside the carton during shipment.



W1596102397

Page 1 of 9 MADE IN MALAYSIA

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small part that may have come loose inside the carton during shipment .



Thank you for purchasing this quality product . Be sure to check all packing material carefully for small part that may have come loose inside the carton during shipment .

PART LIST:									
No.	Description	Sketch	Quantity	No.	Description	Sketch	Quantity		
A	Table Top		1 Pc	Н	Drawer Right Panel		3 Pcs		
В	Cabinet Right Panel		1 Pc	I	Drawer Left Panel		3 Pcs		
С	Cabinet Left Panel	eft	1 Pc	J	Drawer Back Panel		3 Pcs		
				K	Top Drawer Left		1 Pc		
D	Drawer Front Panel		3 Pcs		Panel				
				L	Top Drawer Right Panel		1 Pc		
	Top Drawer Front Panel		1 Pc						
E				М	Top Drawer Back Panel		1 Pc		
	Drawer Bottom Board		4 Pcs		I GIICI	~			
F				N	Front Structure Bone		5 Pcs		
G	Cabinet Back Panel		1 Pc	0	Back Structure Bone		3 Pcs		

Thank you for purchasing this quality product . Be sure to check all packing material carefully for small part that may have come loose inside the carton during shipment .

HARDWARE LIST										
No.	Description	Sketch	Size	Quantity	No.	Description	Sketch	Size	Quantity	
1	Drawer Runner		Standard	4 Sets	6	Wooden Handle	Q		8 Pcs	
	Slide				7	Handle Screw	()mmmm	M4x22	8 Pcs	
2	Dowel		24x8.5	36 Pcs	8	Chipboard	D			
3	Ultra Shallov	v	15x9.5	36 Pcs		Screw	W	M3.5x12	32 Pcs	
	Cam	~ 3)	13,7.5			Panel Screw				
4	CSK Cap Wo Screw	od Omminio	M6x40	16 Pcs	9	(Black)	©ama	M3.5x12	20 Pcs	
5	Wood Dowel		8x30	22 Pcs	10	Allen Key		M4	1 Pc	


Page 4 of 9 MADE IN MALAYSIA


ASSEMBLY INSTRUCTIONS Item No: W1596102397

Description: CHEST

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small part that may have come loose inside the carton during shipment .

Step 1: Prepare the Cabinet Right Panel (B) & Cabinet Left Panel (C) then assemble the Drawer Runner Slide (1) on the pre-drilled holes with Chipboardboard Screw (8). Then insert the Dowel (2) & Wood Dowel (5) on each side of the cabinet as image shown below






ASSEMBLY INSTRUCTIONS Item No: W1596102397


Description: CHEST

Thank you for purchasing this quality product . Be sure to check all packing material carefully for small part that may have come loose inside the carton during shipment .

Step 3: Insert the Dowel (2) onto the pre-drilled holes on the bottom part of Table Top (A).




Step 4: Ready the cabinet structure and flip the Table Top (A) to cover on top of the cabinet. Then tighten the attachment with Ultra Shallow Cam (3) with Dowel pre-installed in previous step 3. You would need to ready a screwdriver to perform this step.




Page 6 of 9 MADE IN MALAYSIA

Thank you for purchasing this quality product . Be sure to check all packing material carefully for small part that may have come loose inside the carton during shipment .

Step 5: Lay the Drawer Front Panel (E) on even-layered flat surface, put in the Dowel (2) on each side and take the Top Drawer L/R Panel (K & L) attach into the Pre-drilled holes of the Front Panel (E), tighten the part with Ultra Shallow Cam (3). Next, slide in the Drawer Bottom Board (F) finish up with screwing the Handle (6) with using Handle Screw (7).



Step 6: Setting up the Drawer with its Top Drawer Back Panel (M) with CSK Cap Wood Screw (4) with the help of Allen Key (10). Assemble the Drawer Runner Slide (1) to the Drawer Panel (K & L) by using Chipboard Screw (8).





Description: CHEST

Thank you for purchasing this quality product . Be sure to check all packing material carefully for small part that may have come loose inside the carton during shipment .

Important: Wood Dowel (5) ONLY to be inserted on pre-drilled holes of Drawer Right Panel (H) & Drawer Left Panel (I)

Step 7: Lay the Drawer Front Panel (D) on even-layered flat surface, put in the Dowel (2) on each side and take the Drawer Panel (H & I) attach into the Pre-drilled holes of the Front Panel, tighten the part with Ultra Shallow Cam (3). Next, slide in the Drawer Bottom Board (F) finish up with screwing the Handle (6) with using Handle Screw (7).






ASSEMBLY INSTRUCTIONS Item No: W1596102397


Description: CHEST

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small part that may have come loose inside the carton during shipment.

Step 9: Cover up the back of cabinet with Cabinet Back Panel (G) by using Panel Screw (Black) (9).



Finally, glide in the drawers and make sure the slide glide in smoothly into the track, not sitting on top of the runner track.



Page 9 of 9 MADE IN MALAYSIA