



This Bistro Chair has multiple parts and may require up to some 30 minutes to assemble.

To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective.

Please read through the instructions herebelow to familiarise the parts and steps before assembly.

Step 1 Unpack and place all parts on a clean soft surface. Step 2 B 6 Attach Backrest(A) to Chair Seat(B) by using Washers, Spring Washers and

Nuts(①).

Tighten the Nut using the Spanner(⁶). **DO NOT OVERTIGHTEN at this stage.**

Step 3 ato D 6 000 С Attach Chair Legs(C)to the Chair Seat(B) by using Washers, Spring Washers and Nuts(1). Tighten the Nuts using the Spanner(6). Repeat this procedure for the remaining Legs. DO NOT OVERTIGHTEN at this stage. Step 4 Adjust low Adjust height for balance for balance Adjust Pre-installed Levellers height for balance Turn the chair right side up.

Upon completion of full assembly and bolted up-all screws can be tightened down.

Adjust the Legs with pre-installed Levellers until the chair is level with the ground.

Your chair is now ready for use.

Care & Maintenance

0

- Do not put hot items directly on furniture surface.
 - Do not clean furniture with harsh cleansers or polish.
 - To obtain the longest lifespan of your outdoor prodcts, minimizing exposure to direct sunlight is recommended.
 - ※ Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
 - To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
- So Solution State St
 - Stains may be removed with mild soap solution and damp cloth.
 - Dust and pick-up spills using a clean, non-colored, lint-free cloth.