

# Assembly & Installation Instructions

ITEM NO.: B080107025

## CAUTION:

Read instructions carefully and turn electricity off at main circuit breaker panel before beginning installation.

## WARNING

Wires and cables are all attached (further wiring is not needed from consumer). When unpacking product, be careful to not pull wires as it may result as a bad connection. Do not plug into electrical outlet until lamp is fully assembled.

## ASSEMBLY INSTRUCTIONS:

Unpack and place all parts on a surface or floor.

1. Assemble stems (A) to stems (B)
2. Assemble legs (A/B) to lamp base (C).
3. Gently pull the cord (I) so that the neck (D) comes into contact with the body (C) .
4. Screw the neck (D) onto the lamp body (C), and straighten the cord (I) .
5. Insert the harp (E) into the neck .
6. Place the shade (F) on the harp (E) and secure shade with finial (G).
7. Loosen then tighten (H) to adjust the lamp height.

## IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug(one blade is wider than the other), as a feature to reduce the risk of electric shock, this plug will fit in a polarized outlet only one way, if the plug does not fit fully in the outlet, reverse the plug. if it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

## CLEANING:

Use only soft cloth to dust and clean fixture. Never use chemicals or abrasive cleaners as it may damage finish.

## Note:

Turn the power off (unplug from the wall outlet) before replacing the bulb. Make sure the bulb has sufficient time to cool down.

