
ASSEMBLY INSTRUCTION SOFA SET - WS327.3



Notice:

- 1. Tighten all screws by 50% before fixing. It is recommended to use an Allen wrench instead of an electric drill.
- 2. Place the item on a flat surface to adjust and ensure stability.
- 3. Gradually tighten all screws with tools.
- 4. If screws do not align with holes during assembly, please loosen all other screws by 50% and continue the assembly process.
- 5. If the item is not stable, please loosen all screws, adjust it on a flat surface, and then tighten all screws again.
- 6. Note: If one or more screws are fully tightened during assembly, there is a chance that others will not align with the holes. Additionally, all holes are designed to be relatively larger to provide more space for adjusting the screws.

