





















RATTAN SWIVEL 3PCS SET

ORIGINAL INSTRUCTION MANUAL




PARTS LIST

A	2×	B	2×
			
C	2×	D	2×
			
E	2×	F	2×
			
G	2×	H	1×
			
I	4×	J	1×
			
		K	2×
			

L  2×	M  M6×40MM 28×	N  M6×35MM 16×
O  M6×15MM 12×	P  24×	Q  80×
R  Spanner 1×	S  Spanner 1×	

Exploded View




ASSEMBLY

Before your installation, please make sure that you have all the parts listed on the manual. If you find that something is missing, please stop installing and contact our customer service immediately. We will solve your issue as soon as possible.


NOTE:

- Please do not completely tighten all the hardwares until the entire assembly is completed!
- In order to let you clearly see the position of the screw holes, we omitted the rattan pattern in the parts on the installation step.



1



2






3




4




Please make sure that the placement of the part E is exactly the same as the picture (Two swing arms are outside the black plastic part), and then proceed to next step of installation.




5




6



7



8



9

