



ASSEMBLY INSTRUCTIONS

BES-S-019


Ax2




Bx2



Cx4




Dx2



Ex6




Fx20




Gx1




1




2




3




4



5



6



7

