




Assembly Instruction


W876S00028




A X 36




N X 4




B X 36




O X 12




C X 16




P X 12




D X 5




Q X 12




E X 52



R X 18




F X 8




S X 8




G X 6




T X 8




H X 6




I X 1




W X 4




J X 1




X X 4



K X 12




Y X 16




L X 36




Z X 2



M X 3







1

B X 24

E X 2

D X 1



2

A X 4

B X 4



C X 8

E X 9

L X 4



M X 3

S X 2








3

- A X 8 
- B X 8 
- E X 9 
- L X 8 
- M X 3 




4



- A X 12 
- C X 4 
- D X 4 
- L X 12 
- S X 4 




5







6

- A X12 
- L X 12 







7

- FX 8 
- TX 8 
- IX 1 



8

- GX 6 
- HX 6 
- JX 1 




9

EX 8







N X 4




10




EX 16




11



12


- P X 12 
- R X 18 
- M X 3 




13

Q X 12 

O X 12 



14




15

K X 12






Y X 12



16

X X 4



17

W X 4 

Y X 4 

Z X 2 