


ASSEMBLY INSTRUCTION FOR ACME FURNITURE

MODEL#LV00830/LV00832

Thank you for purchasing the quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and metal hardware. Compare with all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.

*****Do not fully tighten screws until fully assembled.*****

COFFEE TABLE




DIMENSIONS

Width - 47.64"
Depth - 23.62"
Height - 17.64"

ASSEMBLY INSTRUCTIONS



PRECAUTIONS

Because our products may be challenging for beginners, we deeply understand that you may encounter some difficulties. To avoid discouragement, we have provided some useful tips, as follows.




Enough Open Space -

Ensure that there is enough space for movement during assembly.



Prevent Scratching -

When assembling furniture, use cardboard, blankets or a carpet areas to prevent scratches.



More than two people -

Always have at least two people to help transport and assemble the product to avoid potential injury and/or damage.




Question -

If there is any problem with the assembly process, you can call us.

ASSEMBLY INSTRUCTIONS


CAM LOCK FASTENER

Every cam bolt must have a cam lock connector to hold the parts together.




1.

When assembling, the hardware parts and the wooden board must be kept vertical, and the tools must be in full contact with the hardware groove.




Caution:
Do not use excessive force to avoid over-fastening, or even exceed the entire board.




2.

Insert the cam lock pin into the hole of joint panel.



3.

The cam lock nut opening side (or arrow) aligned with the cam lock pin.



4.

Slowly rotate the cam lock clockwise until it stops rotating.




Caution:
When assembling the cam lock, do not use an electric screwdriver to avoid damage to the board or hardware due to excessive force.


ASSEMBLY INSTRUCTIONS

SLIDE RAIL

The holes of the slide rail are in the same direction as the following page.




DOWEL




















ATTENTION

Inserting wood dowels is likely to be tight, so wood dowels may not easily touch the bottom and damage the side panels during installation. It is recommended to slight hit the wooden pins with a hammer to eliminate the gap between the wood dowel and board.



It is recommended to use white glue to increase the safety of the product. If you are worried about assembly errors, you can temporarily not add it, and then add it after confirming.

PARTS LIST

A X1 Front side**G** X1 Drawer right**M** X1 Back**B** X1 Drawer head**H** X1 Large top**N** X1 Drawer bottom**C** X1 Left side**I** X1 Small top**O** X2 Foot**D** X1 Middle**J** X1 Bottom**P** X2 Foot support**E** X1 Drawer left**K** X1 Right side**Q** X1 Lifter support**F** X1 Drawer back**L** X1 Support

HARDWARE LIST

① X17 Cam bolt 7*35*12.5mm



② X17 Cam lock 15*12mm



③ X13 Dowel 8*30mm




④ X7 Wood screw 8#*1-1/4"




⑤ X2 Wood screw 8#*1"




⑥ X3 Coarse screw 7*11*50mm




⑦ X2 Slide rail 17*350mm




⑧ X4 Wood screw #6*1/2"



⑨ X2 Fixing screw M4*12mm




⑩ X1 Lifter



⑪ X1 Spring



⑫ X26 Wood screw 8#5/8"



⑬ X4 Bolt 2*35mm




⑭ X12 Bolt 2*10mm



⑮ X1 Glue



⑯ X1 Allen wrench



⑰ X4 Adjustable leveler 24mm*1/4*12mm





Attention


Some number parts listed on the instruction sheet may not be in parts bag as they may already be assembled. Carefully check parts and packing materials prior to ordering replacements.

ASSEMBLY INSTRUCTIONS





Step 1.



1) Front side of slide rail needs to match front shape of the board.




2) Tighten the screws in the second hole in the front and the rear end of the inner rail.





ASSEMBLY INSTRUCTIONS

Step 2.





Step 3.




ASSEMBLY INSTRUCTIONS

Step 4.






ASSEMBLY INSTRUCTIONS

Step 5.





ASSEMBLY INSTRUCTIONS

Step 6.




ASSEMBLY INSTRUCTIONS

Step 8.




ASSEMBLY INSTRUCTIONS

Step 7.




ASSEMBLY INSTRUCTIONS

Step 9.




Installing two new springs at the same time might cause the strength of pulling up the top to be too strong; thus, it is recommended to install one spring at first and another one afterward, depends on the situation.



ASSEMBLY INSTRUCTIONS

Step 10.



ASSEMBLY IS COMPLETED.

Make sure the product is rested on a flat surface and does not feel loose or wobbly. If it does, double check that the bolts/screws are secured and properly tightened.