Assembly Instructions

Caution : You must read this before you proceed

# BEDSIDE

Parts List

Label	Picture	Description	QTY
A		BEDSIDE TOP	1
B		LEG	2

Hardware

Label	Picture	Description	QTY
①		Washer (20mmx20mm)	5
②		Bolt (M15mmx35mm)	5
③		Allen Wrench	1
④		Screwdriver (Not Provided)	1
⑤		Hammer (Not Provided)	1
⑥		Power Drill (Not Provided)	1
⑦		Metal Bracket	2
⑧		Wall Plug Screw (M3x30mm)	3
⑨		Wall Plug (30mmx5mm)	2
⑩		Washer	3
⑪		Knob	3
⑫		Product Screw (M3X12mm)	3

Assembly Preparation

Before Beginning Assembly:	

- Read instructions, cover to cover -
- Have 2 adults on hand for assembly -
- Do not assemble on flooring or carpet -
- Assemble on a clean non-marring surface (packing foam) -
- Save all packaging until finished -

Assembly Steps

Overview

BEDSIDE TOP(A)

LEG (B)

This Bedside has multiple parts and may require up to some 30 minutes assemble. The above picture is to help you in putting various parts in to perspective . Please read through the instruction below to familiarise yourself with the parts and steps before assembly.

Step 1

With the help of your adult partner, carefully stood the Bedside (A). Install the Knob (⑪)on the drawers with the help of Screwdriver (④) as pictured above.Repeat the step for all the drawers.

Step 2

With assistance from your adult partner, place the Bedside Top (A) face down as picture, on clean, surface. As shown in "Step2" picture attach Leg (B) to Bedside top (A) using Washer (①),Bolt(②) with Allen Wrench (③).

Step 3

Repeat "Step2" to assemble the other Leg (B) to Bedside top (A). Upon assembly of all the Legs (B), flip the Bedside ,as shown in "Step3".

Tipover Restraint Device Installation Instruction

Usage For Tipover Restraint Device:

To secure the Bedside against the wall, attach two Brackets (⑦) on the wall and the product.

Step 4

4.1

4.2

6

9

5

4.1) Drill two holes on wall at same height as Metal Bracket (⑦) on Bedside (A) with Power Drill (⑥).

**You can mark these points in the ways as below:**

1) Move the Bedside back to the wall. Mark two point same width as Bedside on the wall.

Note : The brackets need to be secured to solid ,load bearing surface . Please use a stud finder (not supplied) if needed to locate the wall frame.

2)Measure the height of the Brackets (⑦) with ruler/measuring tape and mark on wall to keep them accurate and same height and width of the Bedside.

4.2) Insert Wall Plugs (⑨) into drilled holes on wall with Hammer (⑤).

Step 5

Attach Brackets(⑦) to Wall Plugs (⑨) using Wall Plug Screws (⑧) and washer (⑩) with Screwdriver (④).

Step 6

5cm

Move (Bedside to the wall, customer can use one of 3 holes for assembly same as other side.
Connect the Metal Bracket (⑦)) to Bedside with help of Product Screw (⑫) and Screwdriver (④) same as other side.
This Bedside is now ready to use.

Care And Maintence

✓ Furniture may scratch floors. We recommend using furniture pads to protect your floors.

⊘ Do not put hot items directly on furniture surface.

⊘ Do not clean furniture with harsh cleansers or polish.

⊘ Do not place furniture under direct sunlight.

⊘ Do not place furniture near heating or cooling vents.

⊘ Do not write on furniture without a padded barrier to protect the surface.

⊘ Do not place furniture outside . For indoor use only.

⊘ Not for commercial use . For residential use only.

⊘ Stains may be removed with mild soup solution and damp cloth.

⊘ Children should not climb or jump on the furniture.

✓ Dust and pick-up spills using a clean, non-colored lint-free cloth.