# Toy Storage Organizer

USER MANUAL

READ AND SAVE THIS INSTRUCTION FOR FUTURE USE

SAFETY & WARNINGS

ADULT ASSEMBLY REQUIRED.

- This product is intended for indoor, home use only.
- As soon as components are unpacked, please remove and recycle all plastic bags from possible contact with children.
- Provide adult supervision at all times.
- Place on a flat, clean floor. Serious or fatal crushing injuries can occur from shelf tipping over.
- Keep away from fire or any source of ignition.
- Check the product before each use. Defective parts must be replaced immediately as they can impair the function and the safety of the product.
- Do not use the product if it is damaged or defective.
- After installing the product according to the instruction manual, ensure all screws are correctly installed and tightened and that all joints are secure.
- Do not allow children to insert head into bins or between shelves. Heads can become stuck in bins or between shelves.
- Do not let children climb into or on storage unit.
- Clean surfaces with damp cloth, air dry.
- Keep this instruction for future reference.

PART LIST

Side Panel x 2

Top Shelf x 1

Support Bar x 6

Storage Bin x 9

Hanger x 1

Sticker x 2

Screw & Nut set A x 12

Screw B x 5

Plastic Screwdriver x 1

Plastic Wrench x 1

ASSEMBLY

Screw & Nut Set A x 6

Step1
Slide the Nut through the Support Bar, then insert the Bars through the holes on Side Panel, secure the end with Screw A. Rotate the Nut to tighten the set.


Screw B x 2

Step2
Install the Top Shelf, secure it to the Side Panel with 2pcs Screw B. Tighten with the Plastic Screwdriver.

Screw B x 2

Screw & Nut Set A x 6

### Step3
Attach the other Side Panel, secure the Support Bars with 6 sets of Screw & Nut A, and the Top Shelf with 2pcs Screw B.

Screw B x 1

Step4
Install the Hanger, secure it to the Side Panel with 1pc Screw B.

Step5
Insert the Storage Bins into the rack. Put stickers on the Side Panel.