

ASSEMBLY INSTRUCTIONS


TWIN SIZE - MONTESORI HOUSE BED WITH FENCE



WF294208




ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTIONS


1	2	3
Ø10*30mm	Ø6" x 85 mm	Ø6" x 70 mm
Wood dowel (42pcs)	Wood Screws (4pcs)	Wood Screws (18pcs)
4	5	6
Ø6" x 100 mm	Ø6" x 30 mm	(1/4")4.5*58mm
Wood Screws (14pcs)	Wood Screws (2pcs)	Allen Key (1pc)
7	8	
Ø6" x 50 mm	#4*25mm	
Wood Screws (4pcs)	Screw (58pcs)	


ASSEMBLY TOOLS REQUIRED (N








PLEASE BE CAREFUL DO NOT DAMAGE THE HOLE POSITION WHEN YOU USE POWER TOOLS!











COMPLETED

