







Assembly Instructions











Caution : You must read this before you proceed

Wine Cabinet























Parts List

Label	Picture	Description	QTY
A		Top Panel	1
B1		Left Side Panel	1
B2		Right Side Panel	1
C1		Top	1
C2		Upper Center Panel	1





C3		Lower Center Panel	1
D		Divider	2
E		Bottom Panel	1
F		Leg	4
G1		Left Door	1
G2		Right Door	1
H		X - Shelf	2
I		Upper Back Panel	1
J		Center Back Panel	1
K		Lower Back Panel	1

Hardware

Label	Picture	Description	QTY
①		Knob Handle	2
②		Handle Screw (22mm)	2
③		Bolt (M6 x 70mm)	9
④		Allen Wrench (M4 x 60mm)	1
⑤		Cam-Lock (12mm)	27
⑥		Cam-Bolt (34mm)	27
⑦		Wood Dowel (M8 x 30mm)	25
⑧		Chipboard Screw (M4 x 32mm)	3
⑨		Chipboard Screw (M4 x 16mm)	17


⑩		Plastic Corner Support	13
⑪		Chipboard Screw (M3 x 20mm)	13
⑫		PVC Door Stopper	2
⑬		Chipboard Screw (M3 x 16mm)	2
⑭		Chipboard Screw (M3.5 x 12mm)	9
⑮		Wine Glass Holder	2
⑯		DTC Hinges (7/8")	4
⑰		Foam Pad	5
⑱		Philips Head Screwdriver (Not Provided)	1
⑲		Rubber Hammer (Not Provided)	1
⑳		Flat Head Screwdriver (Not Provided)	1

























Cabinet Restraint Device Hardware

②1		Metal Bracket	4
②2		Cabinet Restraint Strap	2
②3		Pan Head Screw (Long)	2
②4		Pan Head Head Screw (Short)	2

Assembly Preparation

Before Beginning Assembly:



	X 2		X 25		X 2		X 2
	X 2		X 3		X 9		X 2
	X 9		X 17		X 2		X 2
	X 1		X 13		X 4		X 1 (Not Provided)
	X 27		X 13		X 5		X 1 (Not Provided)
	X 27		X 2		X 4		X 1 (Not Provided)



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Step

Overview




This Wine Cabinet has multiple parts and may require up to 60 minutes to assemble. To give you an overview of the Wine Cabinet parts, the above picture is provided to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1



Unpack and place all parts on a clean, non marring surface.

Step 2




Place Left Side Panel (B1), the Right Side Panel (B2), the Upper Center Panel (C2), the Lower Center Panel (C3) and the Bottom Panel (E) onto a clean, non-marring surface.

Insert Cam-Bolts ⑥ into the pre-drilled mounting positions.

Use a Philips Head Screwdriver ⑱ to tighten until the shoulder is snug and flushed with the panel.

See illustration below.

Step 3




Place Top Panel (A), Left Side Panel (B1), Right Side Panel (B2), Top (C1), Upper Center Panel (C2), Lower Center Panel (C3) and Divider (D) onto a clean, non-marring surface.

Insert the Cam-Locks ⑤ into the designated mounting position above the mounting position.

See illustration below.

Instructions for Fastening Cam-Bolts




Shoulder is flushed (on the same level) with the panel.


Shoulder is above the panel.

Make sure the Cam-Bolt shoulder is flushed (on the same level) with the panel. If the Shoulder is above the panel, it is inserted incorrectly.

Instructions for Fastening Cam-Bolts to Cam-Locks



When inserting a Cam-Lock, align the arrow on the Cam-Lock with the Cam-Bolt head and insert the Cam-Lock, as shown in the illustrations above.




When tightening the Cam-Lock, the Cam-Bolt head needs to be centered. Use a Flat Screwdriver to turn the Cam-Lock clockwise to lock onto the head of the Cam-Bolt.

Turn until it is snug.


If you over tighten, it could damage the Cam-Lock or the Cam-Bolt.

Step 4




Place the Divider (D) on a material that does not scratch or damage the part. Insert the Wood Dowels ⑦ into the Divider (D) using a Rubber Hammer ⑲. Attach the Lower Center Panel (C3) and the Upper Center Panel (C2) with Divider (D). Use Flat Head Screwdriver ⑳ to lock onto Cam-Bolts ⑥.

Step 5




Insert Wood Dowels ⑦ into the Top (C1), the Upper Center Panel (C2) and the Lower Center Panel (C3) using a Rubber Hammer ⑲. Attach the complete assemble Part (C2),(C3) & (D) and the Top (C1) to the Right Side Panel (B2). Use Flat Head Screwdriver ⑳ to lock onto Cam-Bolts ⑥.

Step 6



Attach the Top Panel (A) to the Top (C1) with Chipboard Screw ⑧ using a Philips Head Screwdriver ⑱.


Step 7



Insert the Upper Back Panel (I) and the Center Back Panel (J) into the groove on the Top (C1), the Upper Center Panel (C2) and the Lower Center Panel (C3) check that the Upper Back Panel (I) and Center Back Panel (J) also fits into the groove on the Right Side Panel (B2).


Insert Wood Dowels ⑦ into Top (C1), the Upper Center Panel (C2) and the Lower Center Panel (C3) using a Rubber Hammer ⑲.

Step 8




Attach the Left Side Panel (B1) to the complete assembly part.
Use a Flat Head Screwdriver (20) and turn clockwise to lock onto the Cam-Bolts (6).
Refer to the instructions on tightening Cam-Locks (5).

Step 9




Insert Wood Dowels (7) into the Left Side Panel (B1) and Right Side Panel (B2) by using a Rubber Hammer (19).
Insert the Lower Back Panel (K) into the groove on the Left Side Panel (B1) and the Right Side Panel (B2).
Check that the Lower Back Panel (K) also fits into the groove on the Lower Center Panel (C3).
Attach the Bottom Panel (E) to the complete assembly part.
Use a Flat Head Screwdriver (20) and turn clockwise to lock onto the Cam-Bolts (6).
Refer to instructions on tightening Cam-Locks (5).

Step 10




Affix the PVC Door Stopper (12) to the mounting position on the Lower Center Panel (C3) with Chipboard Screw (13) by using Philips Head Screwdriver (18).
Place the Wine Glass Holder (15) on the Top (C1) with Chipboard Screw (14) using a Philips Head Screwdriver (18) to tighten.

Step 11




Place the Leg (F) on the Bottom Panel (E) with Bolts (3), using the Allen Wrench (4) to tighten.

Step 12




Peel Foam Pad ⑰ off the backing and apply it to the bottom of Leg (F).

Step 13




Install the Plastic Corner Support ⑩ to the back of Wine Cabinet with Chipboard Screw ⑪ using the Philips Head Screwdriver ⑱ to tighten.

Step 14




Place the Left Door (G1) and the Right Door (G2) with the interior side facing up, as shown, on a material that does not scratch its exterior surface.
Fit Door Wing of DTC Hinge (16) into the mounting position on (G1) and (G2) and align the mounting position on the Door Wing to the pilot mounting position on (G1) and (G2).
Use a Philips Head Screwdriver (18) to drive in Chipboard Screw (9) to fasten the Door Hinge Wing (16) to the Door (G1) and (G2).
Do not tighten the Chipboard Screw (9) completely until both screws on each wing are in place.

Step 15



Place the Hinge Wing (16) on the Right Door (G2) to align the screw mounting position to the pilot mounting position on the Right Side Panel (B2).
Use a Philips Head Screwdriver (18) to insert the Chipboard Screws (9).
Repeat the same step to install the Left Door.
Affix the Knob Handle (1) to the Left Door (G1) and the Right Door (G2) with handle Screws (2) by using Philips Head Screwdriver (18).

Step 16



Place the X - Shelf (H) on the Lower Center Panel (C3) and slot the two pieces together aligning the grooves.

Hinge/Door Adjustment Instructions


Before making any alignment adjustments, check that all of the screws on the hinges are tightened to determine if adjustments are necessary - loose screws on hinges can easily cause door mis-alignment.

For illustrative purposes, only one hinge on each door is shown.

It is necessary to make adjustment to both hinges on the same door.

VERTICAL HEIGHT ADJUSTMENT

Picture:1




For BOTH hinges on the Door (G1) and (G2), loosen the two Chipboard Screw ⑨ in the slotted mounting position on each DTC Hinge ⑯.

(Refer Picture:1) Adjust up or down and then tighten back up.

SIDE TO SIDE ADJUSTMENT

Picture: 2



First, slight loosen the Chipboard Screw ⑨.


Next, turn the adjusting DTC Hinge Screw (16-b) (Refer to Picture :2) on BOTH DTC Hinges ⑩ on the doors (G1) and (G2) for parallel adjustment.

For angled or slanted adjustment adjust the DTC Hinge Screw (16-b) (Refer to Picture:2) on either the top or bottom DTC Hinge ⑩ to straighten the Door (G1) and (G2).

Tighten DTC Hinge Screws (16-a) (Refer to Picture:2) when alignment is completed.

DEPTH OR BINDING ADJUSTMENT

Picture: 3




Slightly unscrew the tightened DTC Hinge Screw (16-a) (Refer to Picture:3) on BOTH DTC Hinge ⑩ .

The Door (G1) and (G2) can now slide in and out a little.

Pull it away or push in slightly to adjust accordingly and re-tighten the DTC Hinge Screw (16-a).(Refer to Picture:3)

Step 17




Your Wine Cabinet is now ready for use.
This Wine Cabinet can be used on a flat, level surface.

Cabinet Restraint Device Installation Instructions

WARNING

Serious or fatal crushing injuries can occur from tipping furniture.
To help prevent tip-over : ALWAYS secure this furniture to the wall using Cabinet Restraint Device
See product instructions for more ways to help prevent furniture tip-over.




HOW TO AFFIX THE SAFETY STRAP

Installation Instruction :












This tip restraint must be attached to a wall stud using the Pan Head Screw (Long) ②③ enclosed.

1. Attach a Metal Bracket ②① securely to the back top rail of the cabinet using the Pan Head Screw (Short) ②④ provided, through the smaller mounting position.
2. Place the other Metal Bracket ②① on the wall over a wall stud and 2 inches below the mounting bracket secured to the back of your unit.
Attach to the wall stud using the Pan Head Screw (Long) ②③ provided , through the smaller mounting position.

3. Place the furniture into position so both mounting brackets are vertically in line.
4. Lace the end of the Cabinet Restraint Strap (22) through the larger mounting position in each mounting bracket. Bring both ends together and slide the flat end through the locking end and draw it through until all slack is removed.
5. Confirm that the Cabinet Restraint Strap (22) is securely laced and locked.



Care & Maintenance

- ✓  ● Furniture may scratch floors. We recommend using furniture pads to protect your floors.
 - ⊘  ● Do not put hot items directly on furniture surface.
 - ⊘  ● Do not clean furniture with harsh cleansers or polish.
 - ⊘  ● Do not place furniture under direct sunlight.
 - ⊘  ● Do not place furniture near heating or cooling vents.
 - ⊘  ● Do not write on furniture without a padded barrier to protect the surface.
 - ⊘  ● Do not place furniture outside . For indoor use only.
 - ⊘  ● Not for commercial use. For residential use only.
 - ⊘  ● Stains may be removed with mild soap solution and damp cloth.
 - ⊘  ● Children should not climb or jump on the furniture.
-
- ✓  ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.