
















# Parts List

Part Number	Description	Quantity
6	Drawer Front	2
17	Wood Slider	4
19	Right Drawer Side	2
20	Left Drawer Side	2
21	Drawer Back	2
23	Drawer Bottom	2
24	Left Side Panel	1
25	Division	1
26	Right Side Panel	1

Part Number	Description	Quantity
28	Top	1
29	Shelf	1
30	Back Panel	1
32	Base Panel	1
35	Top Crossbeam	1
36	Foot	4
37	Bottom Front Crossbeam	2
39	Bottom Side Crossbeam	2



# Hardware List



	Part	Size	Name	Quantity
A		Ø8*30mm	Wood dowel	47
B		Ø8*40mm	Wood dowel	04
C		Ø10*20mm	Wood dowel	12
D		Ø3,0*12mm	Screw	04
E		Ø4,0*25mm	Screw	12
F		Ø3,5*30mm	Screw	18
G		Ø4,0*40mm	Screw	22
H		ø15*30mm	Cam bolt	14
I		ø15*10mm	Cam lock	14
J		-	Handle	02
K		Ø8*8mm	Cam bolt	06
L		-	Plastic lock	06
M		-	Slap hole	06

*The hardware quantities listed above are required for proper assembly.*

*Extra hardware pieces may be included.*

# Step 1

Let's get started. First step is inserting Wooden dowels (C) into Wood Sliders (17)




Tip

## Wood Dowels


Dowels are essential in furniture assembly to create strong, precise connections.

They ensure structural integrity, prevent shifting, and simplify alignment, resulting in sturdier, longer-lasting furniture.



Follow these steps:



1: Select the appropriate size dowel according with step.





2: Insert into drilled hole and press firmly to ensure placement is set.



3: Align the dowel with corresponding piece and press together until secure.

## Step 2

Insert Wooden dowel (A) into Right Drawer Side (19), Left Drawer Side (20), Left Side Panel (24), Division (25), Right Side Panel (26), Top (28), Top Crossbeam (35), Foot (36), Bottom Front Crossbeam (37) and Bottom Side Crossbeam (39).




To keep your product looking its best and scratch-free, try assembling it on a soft surface like carpet or a blanket. This helps prevent any accidental scratches and keeps your furniture in top shape!




# Step 3


Attach Cam Bolt (H), according to the diagram, on Left Side Panel (24), Right Side Panel (26), Shelf (29) and Base Panel (32) using a Phillips Head Screwdriver.



Option 01  
For Drawers in the Right, Attach  
Cam Bolts (H) like these pictures.




Option 02  
For Drawers in the Left, Attach  
Cam Bolts (H) like these pictures.




## Step 4

Do the same to Cam Bolts (K) on Left Side Panel (24) and Right Side Panel (26) using a Phillips Head Screwdriver.




# Step 5

Secure Wood Sliders (17) to Division (25) and Right Side Panel (26) for Drawers in the Right or Left Side Panel (24) for Drawers in the Left. Use a Phillips Head Screwdriver.





## Option 01

For Drawers in the Right, Attach Wood Sliders (17) follow this assembly.






**\*\*\*ATTENTION\*\*\***  
Wood Sliders (17) hole for drawer stop should be facing up.



## Option 02


For Drawers in the Left, Attach Wood Sliders (17) like these pictures.



**\*\*\*ATTENTION\*\*\***  
Wood Sliders (17) hole for drawer stop need to be facing up.

## Step 6



Secure Top Crossbeam (35) to Top (28) using Screw (F) and a Phillips Head Screwdriver.






# Step 7

Assemble Left Side Panel (24) and Right Side Panel (26) to Top (28) fitting Cam Bolts (H) and attaching Cam Locks (I) using a Phillips Head Screwdriver.




## Cam Locks


Cam Locks help securely join two pieces together.  
Follow these easy steps.



1: Insert Cam Bolt into bolt holes on the flat side. Don't over tighten!




2: Assemble both parts together. The cam bolts goes in the drills holes that have a circular hole on the side, you should be able to see the cam bolt through it. After fitting parts together insert the cam lock on the side holes.



3: On the back of the Cam Lock will be a "C" shape. Insert the Cam Lock so the opening of the "C" fits over the Cam Bolt. Tighten with the screwdriver.

## Step 8

Insert Plastic Lock (L) into Shelf (29) using a Hammer if necessary.






# Step 9

Secure Division (25) to Shelf (29) using Cam Lock (I) and a Phillips Head Screwdriver.



## Option 01

For Drawers in the Right, Attach Wood Sliders (17) follow this assembly.



## Option 02


For Drawers in the Left, Attach Wood Sliders (17) like these pictures.



# Step 10

Fit Division (25) and Shelf (29) over the pins. Align the pins on Left Side Panel (24) and Right Side Panel (26) inside the Plastic Lock (L).


This picture show be Right drawer side.  
But Left drawer side is equal assembly step.



# Step 11

Press until you feel the fit or “click”.



This picture show be Right drawer side.  
But Left drawer side is equal assembly step.



# Step 12

Slide Back Panel (30) on the grooves on Left Side Panel (24) and Right Side Panel (26). Then attach Base Panel (32) using Screws (G) and a Phillips Head Screwdriver.





This picture show be Right drawer side.  
But Left drawer side is equal assembly step.



# Step 13


Secure Base Panel (32) to Division (25) attaching Cam Lock (I) using a Phillips Head Screwdriver.

This picture show be Right drawer side.  
But Left drawer side is equal assembly step.



# Step 14


Secure Bottom Front Crossbeam (37) to Foot (36) using Screws (G) and a Phillips Head Screwdriver.






# Step 15

Attach Bottom Side Crossbeam (39) to Foot (36) using Screws (G) and a Phillips Head Screwdriver.



## Step 16



To finish assembling the feet. Secure Bottom Side Crossbeam (39) to Foot (36) using Screws (G) and a Phillips Head Screwdriver.



# Step 17

Now, attach the assembled feet to Base Panel (32) using Screws (G) and a Phillips Head Screwdriver.




This picture show be Right drawer side.  
But Left drawer side is equal assembly step.



# Step 18


Insert Wooden dowels (A) into Wood Sliders (17).

This picture show be Right drawer side.  
But Left drawer side is equal assembly step.



## Step 19

Secure Right Drawer Side (19) and Left Drawer Side (20) to Drawer Front (6) using Screws (F) and a Phillips Head Screwdriver. Slide Drawer Bottom (23) on the grooves on Right and Left Drawer Sides (19,20) fitting in Drawer Front (6). Attach Drawer Back (21) to Right and Left Drawer Side (19,20) using Screws (F) and a Phillips Head Screwdriver.




## Step 20

Secure Handle (J) using Screws (D) and a Phillips Head Screwdriver in the pre drilled holes on the Drawer Front (6).






**2x**



# Step 21

Insert Wooden dowel (B) on the inside of all drawers, with the drawer inside the unit, after having passed the wooden dowel that is in the drawer slide. The dowel is not flush with the panel, it is a little inside the drawer to help when you need to remove the lock dowel to remove the drawer.

This picture show be Right drawer side.  
But Left drawer side is equal assembly step.






# Step 22

Insert the slap hole (M) into the niche.

This picture show be Right drawer side.  
But Left drawer side is equal assembly step.




There are colors options for  
theslaps, choose the  
slapaccording to the color of  
your item.






## Step 23

Secure Top Crossbeam (35) to Left Side Panel (24) and Right Side Panel (26) using Cam Lock (I) and Phillips Head Screwdriver.



# You did it! Enjoy your new Night Stand!



Right drawer side



Left drawer side

